

Bench Assembly Instructions



Step 1

Having removed the packaging and set out the individual parts of your bench, begin by setting down one of the end pieces with location points facing upwards.



Step 2

Now simply build your bench upwards as shown in the photos adjacent. They will be a nice tight fit so you might find a rubber mallet is useful to assemble your bench securely, we recommend using a small piece of cardboard where you strike so you will not damage the bench. The parts should be labelled to help ensure you get the pieces in the right place.



Step 3

Once your seat and back rest (and tie bar where applicable) are in place you are ready to fit the other end piece accordingly, as shown in the photo opposite. Again the fit will be quite tight but this is necessary to ensure the strength and stability of the bench.



Step 4

Now your bench is effectively assembled all that's left to do is secure it in position using the wooden dowels and or screws (depending on the model) which come with each bench (picture above). The dowel holes will be pre drilled and hopefully quite obvious.

Use a rubber mallet to gently ease in the dowels so that they are secure and if they won't go in completely, but the section is secure, cut the dowel to size. This is due to them being universal dowels. Use the screws to secure the seat, pilot holes can be found to the underside.



ADIRONDACK CHAIR ASSEMBLY INSTRUCTIONS

Step 1:

Unpack your chair and set out the parts. You should have a seat, back rest, two arm rests and a packet of fixings.



Step 2:

Place the seat flat on the ground and set the backrest into the rear of the seat section, lining up the holes, as shown in the photo above. Secure the two pieces in place using four of the brass bolts provided. At this stage, do not fully tighten the bolts.

Make sure you match the code on the white labels of the pieces of the chair with a corresponding code on a joining piece. The chairs are handmade, so each joint and pair of holes is specific.



TOP TIP

Undo one end of the bolts slightly. This will extend the bolt, as per the adjacent photo, making it easier to secure during assembly!





Step 3:

Roll the chair over on its side and set the first arm rest in position, as shown in the photo opposite, lining up the holes and securing the pieces together using the brass bolts provided as shown below.

Again, do not fully tighten the bolts at this stage.



Step 4:

The remaining bolt from the arm rest to the backrest can then be fitted, as shown in the photo below. This may need someone to assist in holding the two parts together so you can line up the holes.



Step 5:

Once both of the arm rests are secured in position, you can tighten the bolts. Please do not over tighten the bolts, as this could cause the teak to split!



Step 6:

The chair is complete and ready for use. Time to enjoy your garden in comfort!



ottena.
Premium Handmade Furniture.

CHARLOTTE CHAIR ASSEMBLY INSTRUCTIONS

Step 1:

The chairs will arrive packaged in pairs, each chair will come in 5 pieces which includes 2 arm sections, seat back, seat base and support bar. You will also find a bag of wooden dowels. Each piece of the chair will have a small numbered/lettered label stuck near the a joint which will correspond with the piece designed to go into that particular joint.



Step 2:

Take one of the arm sections and lay it on the floor with the joints facing upwards (do not forget to put some protection down first to save any damage to your chairs). Next, take the back rest, seat base and support bar and fit these sections into their corresponding joints using the numbered/lettered labels for guidance. If the joints are slightly tight going together then a light tap with a rubber mallet will help to locate them but please do this with care as to not damage your chair.



Step 4:

Using a rubber mallet gently knock the wooden dowels into each of the holes ensuring the joint is fully pushed together as you do this. Any excess dowel that is left can either be trimmed with a small hacksaw blade or sanded smooth with sand paper.



Step 3:

Once these parts are located the other arm section can be lowered on top of these parts and fitted together. Please ensure all joints are aligned before pushing together. Once the chair is assembled the wooden dowels will need to be fitted to ensure the chairs are secure and stable.

PLEASE NOTE: THE WOODEN DOWELS ARE A UNIVERSAL LENGTH AND CAUTION MUST BE USED WHEN KNOCKING THEM IN SO NOT TO SPLIT THE TEAK. ANY EXCESS WILL NEED TO BE TRIMMED OR SANDED.



Step 5: Once the dowels are fitted and trimmed/sanded flush, you can place your chairs in your garden and sit back and relax!